



WEBBING WINCH BROTHER INSTRUCTIONS



- WINCH CABLE HOOK MUST ONLY BE ATTACHED TO THE TOP DELTA RING AS SHOWN IN THE GRAPHIC ABOVE
- INTERMEDIATE DELTA RINGS AT ALL OTHER POINTS ARE FOR **SHORTENING EACH LEG ONLY** BY CLIPPING IN THE SNAPHOOKS AS SHOWN ABOVE. **DO NOT** ATTACH THE WINCH CABLE TO THESE POINTS.






*If the stitching on inspection is the same as shown in this image, these winch brothers have been used incorrectly

- DO NOT UNDER ANY CIRCUMSTANCES USE METHODS B OR C AS THIS WILL CAUSE PREMATURE FAILURE AND VOID ANY PRODUCT WARRANTY
- PULLING FROM POINT B OR WILL RESULT IN FORCE BEING APPLIED TO THE LOCKSTITCHED SPLICED IN THE WRONG DIRECTION. PULLING THE WEBBING BACK AGAINST THE STITCHING WILL CAUSE A PREMATURE FAILURE.
- PLEASE SEE THE GRAPHIC BELOW FOR AN EXPLANATION OF THE *LOCKSTITCH CONSTRUCTION


*LOCKSTITCH CONSTRUCTION



LOWER THREAD



When the lock stitch splice is pulled in the direction of design, the upper thread entwines the lower thread in the centre of webbing, this forms a load bearing splice.



When pulled in the wrong direction (against the sewn splice), the force is placed on a single row of stitching resulting in premature failure.



REQUIRE FURTHER ASSISTANCE? CALL US ON 0800 371 185

